

Having TROUBLE with operation?

Please reset your unit

Refer to page of How to reset your unit

Vous avez des PROBLÈMES de fonctionnement?

Réinitialisez votre appareil

Référez-vous à la page intitulée Comment réinitialiser votre appareil

Dear Customer,
This apparatus is in conformance with the valid European directives and standards regarding electromagnetic compatibility and electrical safety.

European representative of Victor Company of Japan, Limited is:
JVC Technical Services Europe GmbH
Postfach 10 05 04
61145 Friedberg
Germany

Cher(e) client(e),
Cet appareil est conforme aux directives et normes européennes en vigueur concernant la compatibilité électromagnétique et à la sécurité électrique.

Représentant européen de la société Victor Company of Japan, Limited:
JVC Technical Services Europe GmbH
Postfach 10 05 04
61145 Friedberg
Allemagne


JVC

ENGLISH


FRANÇAIS

KD-R711

CD RECEIVER / RÉCEPTEUR CD



MP3 WMA Radio Data System



For canceling the display demonstration, see page 4. / Pour annuler la démonstration des affichages, référez-vous à la page 4.

For installation and connections, refer to the separate manual. / Pour l'installation et les raccords, se référer au manuel séparé.

JVC



© 2009 Victor Company of Japan, Limited

1209DTSMDTJEIN

INSTRUCTIONS

MANUEL D'INSTRUCTIONS

GET0649-003A
[E/EU]



Thank you for purchasing a JVC product.

Please read all instructions carefully before operation, to ensure your complete understanding and to obtain the best possible performance from the unit.

IMPORTANT FOR LASER PRODUCTS

1. CLASS 1 LASER PRODUCT

2. **CAUTION:** Do not open the top cover. There are no user serviceable parts inside the unit; leave all servicing to qualified service personnel.

3. **CAUTION:** Visible and/or invisible class 1M laser radiation when open. Do not view directly with optical instruments.

4. REPRODUCTION OF LABEL: CAUTION LABEL, PLACED OUTSIDE THE UNIT.

CAUTION VISIBLE AND/OR INVISIBLE CLASS 1M LASER RADIATION WHEN OPEN. DO NOT VIEW DIRECTLY WITH OPTICAL INSTRUMENTS. IEC60825-1:2001 (EN6)	ATTENTION RAYONNEMENT LASER VISIBLE ET/OU INVISIBLE DE CLASSE 1M LORS QU'EST OUVERT. NE PAS REGARDER DIRECTEMENT AVEC DES INSTRUMENTS OPTIQUES. (FR)	AVISO RADIACION LASER DE CLASE 1M VISIBLE Y/O INVISIBLE CUANDO ESTA ABIERTO. NO MIRAR DIRECTAMENTE CON INSTRUMENTAL OPTICA. (ES)	VARNING SYNLIG OCH/ELLER OSYNLIG LASERSTRÅLNING. KLASS 1M, NÅR DENNA ÄR ÖPPNAD. BETRAKTA EJ STRÅLEN MED OPTISKA INSTRUMENT. (S)	注意 ここを覗くと有害な 光があなたに有害な レーザー放射が 出ます。 光学顕微鏡で直接 見ないでください。 (JP)	CAUTION VISIBLE AND/OR INVISIBLE CLASS II LASER RADIATION WHEN OPEN. DO NOT STARE INTO BEAM. FDA 21 CFR (EN6)
--	--	--	---	---	--



Products

Battery

Information for Users on Disposal of Old Equipment and Batteries

[European Union only]

These symbols indicate that the product and the battery with this symbol should not be disposed as general household waste at its end-of-life.

If you wish to dispose of this product and the battery, please do so in accordance with applicable national legislation or other rules in your country and municipality.

By disposing of this product correctly, you will help to conserve natural resources and will help prevent potential negative effects on the environment and human health.

Notice:

The sign Pb below the symbol for batteries indicates that this battery contains lead.

Warning:

If you need to operate the unit while driving, be sure to look around carefully or you may be involved in a traffic accident.

For safety...

- Do not raise the volume level too much, as this will block outside sounds, making driving dangerous.
- Stop the car before performing any complicated operations.

Temperature inside the car...

If you have parked the car for a long time in hot or cold weather, wait until the temperature in the car becomes normal before operating the unit.


Caution on volume setting:

Digital devices (CD/USB) produce very little noise compared with other sources. Lower the volume before playing these digital sources to avoid damaging the speakers by the sudden increase of the output level.




How to read this manual

The following icons/symbols are used to indicate:


 [Hold] Press and hold the button(s) until the desired operation begins.

 Turn the control dial.


 Turn the control dial to make a selection, then press to confirm.

 XX Reference page number


<XXXX> Menu setting item

 Continued on the next page

How to attach/detach the control panel



How to reset your unit



Your preset adjustments will also be erased (except the registered Bluetooth device). (🔍 14)

How to forcibly eject a disc



- You can forcibly eject the loaded disc even if the disc is locked. To lock/unlock the disc, 🔍 10.
- Be careful not to drop the disc when it ejects.
- If this does not work, reset your unit.

CONTENTS

- 3 How to read this manual
- 3 How to attach/detach the control panel
- 3 How to reset your unit
- 3 How to forcibly eject a disc
- 4 Canceling the display demonstration**
- 4 Setting the clock**
- 5 Preparing the remote controller (RM-RK50)**
- 6 Basic operations**
- 7 Listening to the radio**
- 10 Listening to a disc**
- 11 Listening to the USB device**
- 13 Using the Bluetooth® device**
 - 15 Using a Bluetooth mobile phone
 - 17 Using a Bluetooth audio player
 - 18 Changing the Bluetooth settings
- 20 Listening to the iPod/iPhone**
- 22 Listening to the other external components**
- 23 Selecting a preset sound mode**
- 24 Menu operations**
- 27 More about this unit**
- 31 Maintenance**
- 32 Troubleshooting**
- 36 Specifications**

Canceling the display demonstration

1 Turn on the power.



4 Select <DEMO OFF>.



2 MENU [Hold]



5



3



6 Finish the procedure.



Setting the clock

1 Turn on the power.



6 Adjust the minute.



2 MENU [Hold]



7



3 Select <CLOCK>.



7 Select <24H/12H>.




8



4 Select <CLOCK SET>.



8 Select <24 HOUR> or <12 HOUR>.



5 Adjust the hour.




9 Finish the procedure.




Preparing the remote controller (RM-RK50)

When you use the remote controller for the first time, pull out the insulation sheet.



If the effectiveness of the remote controller decreases, replace the battery.

Replacing the lithium coin battery



Caution:

- Danger of explosion if battery is incorrectly replaced. Replace only with the same or equivalent type.
- Battery shall not be exposed to excessive heat such as sunshine, fire, or the like.

Warning (to prevent accidents and damage):


- Do not install any battery other than CR2025 or its equivalent.
- Do not leave the remote controller in a place (such as dashboards) exposed to direct sunlight for a long time.
- Store the battery in a place where children cannot reach.
- Do not recharge, short, disassemble, heat the battery, or dispose of it in a fire.
- Do not leave the battery with other metallic materials.
- Do not poke the battery with tweezers or similar tools.
- Wrap the battery with tape and insulate when throwing away or saving it.

This unit is equipped with the steering wheel remote control function.









Before operating, connect an exclusive remote adapter (not supplied) which matches your car to the steering wheel remote input terminal on the rear of the unit.

- For details, refer also to the instructions supplied with the remote adapter.






Basic operations





When you press or hold the following button(s)...

Main unit	Remote controller	General operation
		Turns on. • When the power is on, pressing ATT on the remote controller also mutes the sound or pauses. Press ATT again to cancel muting or resume playback. Turns off if pressed and held.
		Selects the available sources (if the power is turned on). • If the source is ready, playback also starts.
		Adjusts the volume level.
		Selects items.
		<ul style="list-style-type: none"> • Mutes the sound while listening to a source. If the source is "CD," "USB FRONT/USB REAR," or "IPOD-FRONT/IPOD-REAR," playback pauses. Press the control dial again to cancel muting or resume playback. • Enters playback mode menu directly if pressed and held. • Confirms selection.




Main unit	Remote controller	General operation
	SOUND 	Selects the sound mode. • Enters tone level adjustment directly (📞 23) if pressed and held EQ/BASS-TRE on the main unit.
	—	• Enters “Call Menu” screen or answers incoming call when the unit rings. • Ends a call if pressed and held.
	—	• Activates/deactivates TA Standby Reception. • Enters PTY Searching mode if pressed and held. • Returns to the previous menu.
	—	Power off : Checks the current clock time. Power on : Changes the display information.

Listening to the radio

-  → “FM” or “AM”
-  “ST” lights up when receiving an FM stereo broadcast with sufficient signal strength.

Manual search





“M” flashes, then press the button repeatedly.
[Hold]

Automatic presetting (FM)—SSM (Strong-station Sequential Memory)



You can preset up to 18 stations for FM.

While listening to a station...

When an FM stereo broadcast is hard to receive

-  [Hold]
- 
⇒ <TUNER> ⇒ <MONO> ⇒
<MONO ON>
Reception improves, but stereo effect will be lost.

To restore the stereo effect, repeat the same procedure to select <MONO OFF>.

-  [Hold]
- 
⇒ <TUNER> ⇒ <SSM> ⇒
<SSM 01 – 06> / <SSM 07 – 12> /
<SSM 13 – 18>
“SSM” flashes and local stations with the strongest signals are searched and stored automatically.

To preset another 6 stations, repeat the above procedure by selecting one of the other 6 SSM setting ranges.





Manual presetting (FM/AM)

You can preset up to 18 stations for FM and 6 stations for AM.


Ex.: Storing FM station of 92.50 MHz into preset number "04."



⇒ "92.50MHz"




"PRESET MODE" flashes.




⇒ Selects preset number "04."

"P04" flashes and "MEMORY" appears.

Selecting a preset station



or



Changing the display information



Frequency → Clock → (back to the beginning)

Using the remote controller



▲U/D▼ : Changes the preset stations

◀R/F▶ : Searches for stations


The following features are available only for FM Radio Data System stations.

Searching for your favourite FM Radio Data System programme—PTY Search

You can tune in to a station broadcasting your favourite programme by searching for a PTY code.



The last selected PTY code appears.



⇒ Select one of your favourite programme types or a PTY code, and start searching.

If there is a station broadcasting a programme of the same PTY code as you have selected, that station is tuned in.

PTY codes: NEWS, AFFAIRS, INFO, SPORT, EDUCATE, DRAMA, CULTURE, SCIENCE, VARIED, POP M (music), ROCK M (music), EASY M (music), LIGHT M (music), CLASSICS, OTHER M (music), WEATHER, FINANCE, CHILDREN, SOCIAL, RELIGION, PHONE IN, TRAVEL, LEISURE, JAZZ, COUNTRY, NATION M (music), OLDDIES, FOLK M (music), DOCUMENT






Standby receptions

TA Standby Reception

TA Standby Reception allows the unit to switch temporarily to Traffic Announcement (TA) from any source other than AM.

- The volume changes to the preset TA volume level if the current level is lower than the preset level. (<TA VOLUME>,  25)

To activate TA Standby Reception



If the TP indicator lights up, TA Standby Reception is activated.
If the TP indicator flashes, TA Standby Reception is not yet activated.

- To activate the reception, tune in to another station providing Radio Data System signals required for TA Standby Reception.
- To deactivate the reception, press **T/P BACK** again.


PTY Standby Reception

PTY Standby Reception allows the unit to switch temporarily to your favourite PTY programme from any source other than AM.

To activate and select your favourite PTY code for PTY Standby Reception, see <PTY-STANDBY> (25)

If the PTY indicator lights up, PTY Standby Reception is activated.


If the PTY indicator flashes, PTY Standby Reception is not yet activated.

- To activate the reception, tune in to another station providing these signals.
- To deactivate the reception, select <PTY OFF> ( 25) for the PTY code. The PTY indicator goes off.
- The unit will not switch to Traffic Announcement or PTY programme when a call connection is established through "BT-PHONE."

Tracing the same programme— Network-Tracking Reception


When driving in an area where FM reception is not sufficient enough, this unit automatically tunes in to another FM Radio Data System station of the same network, possibly broadcasting the same programme with stronger signals.

Programme A broadcasting on different frequency areas (01 – 05)



To change the Network-Tracking Reception setting, see <AF-REG> ( 25).

Automatic station selection— Programme Search

Usually when you select a preset number, the station preset in that number is tuned in. If the signals from the FM Radio Data System preset station are not sufficient for good reception, this unit, using the AF data, tunes in to another frequency possibly broadcasting the same programme as the original preset station is broadcasting. (<P-SEARCH>,  25)

Changing the display information



Station name (PS) → Station Frequency → Programme type (PTY) → Clock → (back to the beginning)



Listening to a disc

1



⇒ Turn on the power.

2




All tracks will be played repeatedly until you change the source or eject the disc.

Stopping playback and ejecting the disc



"NO DISC" appears.
Remove the disc, then press **⏻/SOURCE** to listen to another playback source.

2




⇒ Select your desired item.
MP3/WMA: Select your desired folder, then the desired track by repeating this step.

Prohibiting disc ejection



To cancel the prohibition, repeat the same procedure.

- If the MP3/WMA disc contains many tracks, you can fast search (± 10 , ± 100 , ± 1000) through the disc by turning the control dial quickly.
- To return to the previous menu, press **T/P BACK**.



Selects folder of the MP3/WMA



Selects track



Fast-forwards or reverses the track
[Hold]

Selecting a folder/track on the list

While listening to a disc...

1



⇒ Enter the list menu.

For MP3/WMA disc, you can also use the search menu (A to Z, 0 to 9, and OTHERS) to scroll through the list menu.

- "OTHERS" appears if the 1st character is not A to Z or 0 to 9, such as #, —, !, and etc.

While in list menu...

- 1 Press **▲/▼** to show the search menu.
 - The first character of the current folder/file name appears.
- 2 Press **▲/▼** to select your desired character. Then press the control dial to confirm.
 - The track list with the selected character appears.
- 3 Turn the control dial to select your desired track. Then press the control dial to confirm.




- Only the existing characters will be shown on the search menu.
- Press and hold **▲/▼** to continuously change the character of the search menu.



- If your disc contains many tracks, searching take some time.

Selecting the playback modes

You can use only one of the following playback modes at a time.

- 1  [Hold]
- 2 
⇒ "REPEAT" ↔ "RANDOM"
- 3 

REPEAT

TRACK RPT : Repeats current track

FOLDER RPT : Repeats current folder

RANDOM

FOLDER RND : Randomly plays all tracks of current folder, then tracks of next folders

ALL RND : Randomly plays all tracks

To cancel repeat play or random play, select "RPT OFF" or "RND OFF."

Changing the display information



Disc title/Album name/performer (folder name)* → Track title (file name)* → Current track number with the elapsed playing time → Current track number with the clock time → (back to the beginning)

* If the current disc is an audio CD (except for CD Text), "NO NAME" appears.

If an MP3/WMA file does not have Tag information or <TAG DISPLAY> is set to <TAG OFF> (🗨 24), folder name and file name appear.

Using the remote controller



▲ U/D ▼ : Selects folder of the MP3/WMA

◀ R/F ▶ : Selects track

◀ R/F ▶ : Fast-forwards or [Hold] reverses the track


Listening to the USB device

This unit is equipped with two USB input terminals (on the control panel and USB cable from the rear of the unit). You can use these two terminals at the same time.

- You can also connect a USB Bluetooth Adapter, KS-UBT1 (supplied), (🗨 13) and/or an Apple iPod/iPhone (🗨 20) to the USB input terminal(s).

This unit can play MP3/WMA/WAV tracks stored in a USB mass storage class device (such as a USB memory, Digital Audio Player, etc.).





If you have turned off the power (without detaching the USB device)...

Pressing turns on the power and playback starts from where it has been stopped previously.

- If a different USB device is currently attached, playback starts from the beginning.

Stopping playback and detaching the USB device

Straightly pull it out from the unit. "NO USB" appears. Press to listen to another playback source.

You can operate the USB device in the same way you operate the files on a disc. 10, 11

- You can listen to WAV files by following the MP3/WMA file operations. 10, 11

Cautions:

- Avoid using the USB device if it might hinder your safety driving.
- While "READING" is shown on the display:
 - Do not pull out and attach the USB device repeatedly.
 - Do not pull out or attach another USB device.

- Do not start the car engine if a USB device is connected.
- This unit may not be able to play the files depending on the type of USB device.
- Operation and power supply may not work as intended for some USB devices.
- You cannot connect a computer to the USB input terminal of the unit.
- Make sure all important data has been backed up to avoid losing the data.
- Electrostatic shock at connecting a USB device may cause abnormal playback of the device. In this case, disconnect the USB device then reset this unit and the USB device.
- Do not leave a USB device in the car, expose to direct sunlight, or high temperature to avoid deformation or cause damages to the device.
- Some USB devices may not work immediately after you turn on the power.
- The detect time and response time may be very long for some USB devices (such as Digital Audio Player, etc.).
- For more details about USB operations, 29, 30.



Using the Bluetooth® device



Bluetooth is a short-range wireless radio communication technology for the mobile device such as mobile phones, portable PCs, and other devices. The Bluetooth devices can be connected without cables and communicate with each other.

- Refer to pages **i** and **ii** at the end of the manual to check the countries where you may use the Bluetooth® function.

Bluetooth profile


This unit supports the following Bluetooth profiles;

HFP (Hands-Free Profile) 1.5 ; OPP (Object Push Profile) 1.1 ; PBAP (Phonebook Access Profile) 1.0 ; A2DP (Advanced Audio Distribution Profile) 1.2 ; AVRCP (Audio/Video Remote Control Profile) 1.3

Refer also to the instructions supplied with the Bluetooth device.

Preparation:

- Connect the supplied USB Bluetooth Adapter (KS-UBT1) to one of the USB input terminals of the unit.
- Operate the device to turn on its Bluetooth function.



Only one USB Bluetooth Adapter can be detected at a time.

Pairing a device


When you connect a Bluetooth device to the unit for the first time, make pairing between the unit and the device.

- Once the connection is established, it is registered in the unit even if you reset the unit. Up to five devices can be registered in total.
- Only one device for Bluetooth phone and one for Bluetooth audio can be connected at a time.





1  [Hold]

2 

⇒ <BLUETOOTH> ⇒ <NEW PAIRING>

3 

⇒ Enter a PIN (Personal Identification Number) code in to the unit.

You can enter any number you like (1-digit to 16-digit number).

[Initial: 0000]

- Some devices have their own PIN code. Enter the specified PIN code in to the unit.


4 Repeat step 3 until you have finished entering the PIN code.

5 

⇒ Confirm the entry.

“SEARCH NOW” and “USING PHONE” appear alternately on the display.

6 Use the Bluetooth device to search. On the device to be connected, enter the same PIN code you have just entered for this unit. “PAIRING OK” and “[Device Name]” appear alternately when the pairing is established.


 appears when Bluetooth connection is established.

7 Use the Bluetooth device to connect* when “CONNECT NOW” and “USING PHONE” alternate on the display.

- Refer to the table on the right column for connectivity results shown on the display.


*Operations may be different according to the connected device.

Display result	Hands-Free Call	Audio Streaming
CONNECT OK ↔ [Device Name]	○	○
H.FREE OK ↔ [Device Name]	○	—
A. STREAM OK ↔ [Device Name]	—	○
CONNCT FAIL ↔ TRY CONNECT	—	—


The device remains registered even after you disconnect the device. Use <CONNECT PH> or <CONNECT AU> (or activate <AUTO CNNECT>,  19) to connect the same device from next time on.

Deleting a registered device


1  [Hold]

2 

⇒ <BLUETOOTH> ⇒ <DELETE PAIR>

3 

⇒ Select a device you want to delete.


4 

⇒ Select <DELETE YES> to confirm. “DELETED” appears when the device is deleted.

- If <DELETE NO> is selected, the unit returns to step 3 above.




Connecting/disconnecting a registered device



⇒ <BLUETOOTH> ⇒ <CONNECT PH/
CONNECT AU> or <DISCONNT PH/
DISCONNT AU>.

- For connecting a device, go to step 3.
- For disconnecting a device, "DISCONNECT" and "[Device Name]" appear alternately on the display when the device is disconnected.




⇒ Select a device you want to connect.
• "CONNECTING" and "[Device Name]" appear alternately, then "CONNECTED" and "[Device Name]" appear alternately on the display when the device is connected.

Using a Bluetooth mobile phone






Making a call



⇒ Enter "Call Menu" screen.



⇒ Select the method to make a call.
• **DIALED***1: Shows the list of the phone numbers you have dialed. Go to the following step.
• **RECEIVED***1: Shows the list of the received calls. Go to the following step.

- **MISSED CALL***1: Shows the list of the missed calls. Go to the following step.
- **PHONEBOOK***2: Shows the name/ phone number of the phonebook registered in the unit or from the connected phone*3. Go to the following step.
 - To copy the phonebook memory, <P. BOOK WAIT>,  19.
 - If the phonebook contains many numbers, you can fast search (± 10 , ± 100 , ± 1000 numbers) through the phonebook by turning the control dial quickly.
 - To search through the phonebook,  16.
- **DIAL NUMBER**: Shows the "Dial Number" screen. ( 16)
- **VOICE DIAL** (only accessible when the connected mobile phone has the voice recognition system): Speak the name (registered words) you want to call when "SAY NAME" appears*4, *5.
 - *1 "NO HISTORY" appears if there is no history stored.
 - *2 "NO DATA" or "SEND P. BOOK"  "MANUALLY" appears depending on the <P. BOOK SEL> settings.
 - *3 Depends on the <P. BOOK SEL> settings,  19.
 - *4 Operations may be different according to the connected device.
 - *5 "NOT SUPPORT" appears if the connected phone does not support this feature.



⇒ Select the name/phone number you want to call.
• When the sound is stopped or interrupted during the use of a Bluetooth device, turn off, then turn on the unit.
-If the sound is not yet restored, connect the device again using <CONNECT PH>.





How to enter phone number

- 1 Turn the control dial to select a number.



- 2 Press to move the entry position.
- 3 Repeat steps 1 and 2 until you finish entering the phone number.
- 4 Press the control dial to confirm the entry.

How to delete name/phone number


Only when <PB IN UNIT> is selected for <P. BOOK SEL>, 19.

- 1 Press to enter "Call Menu" screen.
- 2 Display the list of name/phone numbers using one of the dialing method (see step 2 of "Making a call," 15).
- 3 Turn the control dial to select the name/phone number you want to delete.
- 4 Press and hold **T/P BACK** to enter the "Delete Entries" screen.
- 5 Turn the control dial to select "DELETE" or "DELETE ALL."
 - If "DELETE" is selected, the selected name/phone number in step 3 is deleted.
 - If "DELETE ALL" is selected, the listed numbers in step 2 selection are deleted.
- 6 Press the control dial to confirm.

Selecting a contact from the phonebook



⇒ Enter "Call Menu" screen.



⇒ <PHONEBOOK>

- 3




⇒ Show the search menu (A to Z, 0 to 9, and OTHERS).

The first character of the first contact on the phonebook appears.

- "OTHERS" appears if the 1st character is not A to Z or 0 to 9, such as #, —, !, and etc.


- 4



⇒ Select your desired character.

The name list of the selected character appears.

- 5



⇒ Select your desired contact.

- To return to the previous menu, press **T/P BACK**.

- Only the existing characters will be shown on the search menu.
- Press and hold to continuously change the character of the search menu.
- If your phonebook contains many contacts, searching take some time.

Receiving a call

When a call comes in, the source is automatically changed to "BT FRONT/BT REAR." "RECEIVING" appears for a while, then the phone number or name appears on the display.





When <AUTO ANSWER> is activated....

The unit answers the incoming calls automatically, 19.

- Press or the control dial to answer the incoming call when <AUTO ANSWER> is deactivated.
- Press / to adjust the microphone volume (01 – 03) during a phone call conversation. To preset the microphone volume, 19.
- Press / to turn on/off the Noise Reduction and Echo Cancellation mode. (19)

To end the call an incoming call, press and hold or the control dial.

Switching conversation media (the unit/ mobile phone)

Press the control dial during a phone call conversation, then continue your conversation using the other media.

- Operations may be different according to the connected Bluetooth device.

Switching the connected mobile phone

You can switch the current connected mobile phone to the last connected mobile phone.



and “CONNECTING” flashes on the display. When the last connected phone is being reconnected again, “CONNECTED” and “[Device Name]” appear alternately on the display. Now you can use the last connected mobile phone with the unit.

Arriving of a text message

When a text message comes in, the unit rings if your mobile phone is compatible with text message and <MSG NOTICE> is set to <ON> (19).

- You cannot read, edit, or send a message through the unit.

Using the remote controller

	▲ U/D ▼ / : Answers calls ◀ R/F ▶ / SOURCE
	▲ U/D ▼ / : Rejects calls ◀ R/F ▶ / SOURCE [Hold]
	: Switches the conversation media (between the unit and mobile phone) during a phone call conversation

Using a Bluetooth audio player

Operations and display indications differ depending on their availability on the connected device.



⇒ Select “BT FRONT” or “BT REAR.”


- If playback does not start automatically, operate the Bluetooth audio player to start playback.



Starts or resumes playback



Mutes the sound



Selects group/folder



Forward skips or reverse skips



Fast-forwards or reverses the track





Using the remote controller




◀R/F▶ : Reverse skips/
Forward skips


◀R/F▶ : Fast-forwards or
[Hold] reverses the track

Selecting the playback modes

• For Bluetooth devices that support AVRCP 1.3.



⇒ "REPEAT" ↔ "RANDOM"



REPEAT

TRACK : Repeats current track

ALL : Repeats all tracks

GROUP : Repeats all track of current
group

RANDOM

ALL : Randomly plays all tracks

GROUP : Randomly plays all track of
current group

To cancel repeat play or random play, select
"RPT OFF" or "RND OFF."

• To return to the previous menu, press
T/P BACK.

Changing the display information



**Current track number with the elapsed
playing time → Current track number with
the clock time → Album name/performer
→ Track title →** (back to the beginning)

Warning messages

ERROR CNCT : The device is registered but
the connection has failed. Use <CONNECT
PH/CONNECT AU> to connect the device
again.

ERROR : Try the operation again. If <ERROR>
appears again, check if the device supports
the function you have tried.


PLEASE WAIT : The unit is preparing to use
the Bluetooth function. If the message does
not disappear, turn off and turn on the unit,
then connect the device again (or reset the
unit).

HW ERROR : Reset the unit and try the
operation again. If "HW ERROR" appears
again, consult your nearest JVC car audio
dealers.


Bluetooth Information:

If you wish to receive more information about
Bluetooth, visit the following JVC web site:
<<http://www.jvc.co.jp/english/car/>> (English
website only).

Changing the Bluetooth settings



⇒ <BLUETOOTH> ⇒ <SETTINGS>



⇒ Select a setting item, then repeat
the procedure to change the setting
accordingly.



• To return to the previous menu, press

T/P BACK.

• To exit from the menu, press **DISP** or **MENU**.





Setting item	Selectable setting, [Initial: <u>Underlined</u>]
AUTO CNNT	<ul style="list-style-type: none"> • <u>LAST</u> : The connection is established automatically with the last connected Bluetooth device when you turn on the unit. • <u>OFF</u> : The unit does not connect the Bluetooth device automatically. Connect the device manually. ( 15)
AUTO ANSWER	<ul style="list-style-type: none"> • <u>ON</u> : The unit answers the incoming calls automatically. • <u>OFF</u> : The unit does not answer the calls automatically. Answer the calls manually. ( 16, 17)
MSG NOTICE	<ul style="list-style-type: none"> • <u>ON</u> : The unit informs you of the arrival of a message by ringing and displaying "RCV MESSAGE." • <u>OFF</u> : The unit does not inform you of the arrival of a message.
MIC LEVEL	— : Adjust the volume of the microphone connected to the unit. [LEVEL 01/02/03]
NR/EC MODE	<ul style="list-style-type: none"> • <u>ON</u> : The unit adjusts the Noise Reduction and Echo Cancellation of the microphone connected to the unit for clearer sound. • <u>OFF</u> : Cancels.
RING TONE	<ul style="list-style-type: none"> • <u>IN UNIT</u> : The unit rings to alert you when a call/Text Message comes in. CALL: Select your preferred ring tone when a call comes in. [TONE 1/2/3] MESSAGE: Select your preferred ring tone when a Text Message comes in. [TONE 1/2/3] • IN PHONE : The unit rings (using the connected phones' ring tone) to alert you when a call/Text Message comes in. (The connected mobile phone rings if it does not support this feature.)
P. BOOK SEL*¹	<ul style="list-style-type: none"> • <u>PB IN PHONE</u> : The unit browses the phonebook of the connected phone. • <u>PB IN UNIT</u> : The unit browses the phonebook registered in the unit.
P. BOOK WAIT	— : You can copy the phonebook memory of a mobile phone into the unit (via OPP). Enter the PIN code to the unit to transfer the phonebook into the unit. You can transfer a maximum of 400 numbers.
INITIALIZE	<ul style="list-style-type: none"> • YES : Initialize all the Bluetooth settings (including stored pairing, phonebook, and etc.). • <u>NO</u> : Cancels.
INFORMATION	<ul style="list-style-type: none"> • MY BT NAME : Shows the unit name. • MY ADDRESS : Shows address of USB Bluetooth Adapter. • BT SW VER : Shows the software version. • PH CNNT DEV*² : Shows connected phone name. • AU CNNT DEV*² : Shows connected audio device name.

*¹ Selectable only when the connected phone supports PBAP.

*² Displayed only when a Bluetooth phone/audio player is connected.



Listening to the iPod/iPhone

You can connect the iPod/iPhone using the USB 2.0 cable (accessory of the iPod/iPhone) to the USB input terminal on the control panel or USB cable from the rear of the unit.


There are three control terminals: <HEAD MODE>, control by this unit; <IPOD MODE>, control by the connected iPod/iPhone; <EXT MODE>, the sound of any functions (musics, games, applications, etc.) running on the connected iPod/iPhone is emitted through the speakers connected to this unit.

Preparation:

Select the controlling terminal, <HEAD MODE>, <IPOD MODE>, or <EXT MODE> for iPod playback:

- Press and hold **T/P BACK** button.
- Make the selection from <IPOD SWITCH> setting,  27.

The operations explained below are under <HEAD MODE>.



Playback starts automatically.

Stopping playback and detaching the iPod/iPhone

Straightly pull the USB 2.0 cable out from the unit.

"NO USB" appears. Press **SOURCE** to listen to another playback source.

- For details, refer also to the instructions supplied with your iPod/iPhone.

Caution:

- Some of the applications in the connected iPod/iPhone may not work correctly with this unit.
- Avoid using the iPod/iPhone if it might hinder your safety while driving.
- Make sure all important data has been backed up to avoid losing the data.



The following is not applicable in <EXT MODE>.



Starts playback or pauses/
resumes playback
• While in <EXT MODE>, the
sound mutes.



Selects track or
chapter



[Hold]

Fast-forwards or
reverses the track


Selecting a track from the menu

The following is not applicable in
<IPOD MODE> and <EXT MODE>.

1




2



⇒ Select the desired menu.

PLAYLISTS ↔ ARTISTS ↔ ALBUMS
↔ SONGS ↔ PODCASTS ↔
GENRES ↔ COMPOSERS ↔
AUDIOBOOKS ↔ (back to the
beginning)

3



⇒ Select your desired track.

Repeat this procedure until the desired
track is selected.

- If the selected menu contains many tracks,
you can fast search (± 10 , ± 100 , ± 1000)
through the menu by turning the control dial
quickly.
- To return to the previous menu, press
T/P BACK.

You can also use the search menu (A to Z and 0
to 9) to scroll through the desired menu.

After you have selected your desired menu (in
step 2)...

1 Press ▲/▼ to show the search menu.

- The first character of the current file name
appears.

2 Press ▲/▼ to select your desired character.
Then press the control dial to confirm.

- The track list with the selected character
appears.

3 Turn the control dial to select your desired
track. Then press the control dial to confirm.

- Only the existing characters will be shown on
the search menu.
- Press and hold ▲/▼ to continuously change
the character of the search menu.
- If your iPod/iPhone contains many tracks,
searching take some time.
- Searching may not work on some of the layers
of the selected menu.


Selecting the playback modes

The following is not applicable in
<IPOD MODE> and <EXT MODE>.

1



2




⇒ "REPEAT" ↔ "RANDOM"





3



REPEAT

ONE RPT : Functions the same as "Repeat One" of the iPod

ALL RPT : Functions the same as "Repeat All" of the iPod

RANDOM

SONG RND : Functions the same as "Shuffle Songs" of the iPod

ALBUM RND : Functions the same as "Shuffle Albums" of the iPod

- To cancel repeat play or random play, select "RPT OFF" or "RND OFF."
- "ALBUM RND" is not available for some iPod/iPhone.
- To return to the previous menu, press

T/P BACK.

Changing the display information



Album name/performer → Track title →
Current track number with the elapsed playing time → **Current track number with the clock time** → (back to the beginning)
 In <EXT MODE>: **EXT MODE** ↔ **EXT MODE with clock time**

Using the remote controller

The following is not applicable in <EXT MODE>.



◀R/F▶ : Selects track or chapter

◀R/F▶ : Fast-forwards or [Hold] reverses the track

Notice:

When operating an iPod, some operations may not be performed correctly or as intended. In this case, visit the following JVC web site: <<http://www.jvc.co.jp/english/car/>> (English website only).

Listening to the other external components

You can connect an external component to the AUX (auxiliary) input jack on the control panel.

Preparation:

Make sure <AUX ON> is selected for the <SRC SELECT> → <AUX IN> setting. (☞ 27)

- For details, refer also to the instructions supplied with the external components.



⇒ "AUX IN"

2 Turn on the connected component and start playing the source.




⇒ Adjust the volume.

4 Adjust the sound as you want. (☞ 23)



Connecting an external component to the AUX input jack




Selecting a preset sound mode

You can select a preset sound mode suitable for the music genre.



FLAT → **NATURAL** → **DYNAMIC** → **VOCAL BOOST** → **BASS BOOST** → **USER** → (back to the beginning)

While listening, you can adjust the tone level of the selected sound mode.




Adjust the level (-06 to +06) of the selected tone (BASS / MID / TRE).


The sound mode is automatically stored and changed to "USER."

Storing your own sound mode

You can store your own adjustments in memory.



⇒ <PRO EQ> ⇒ <BASS> / <MIDDLE> / <TREBLE>



Adjust the sound elements of the selected tone. (EQ table on the left)



4 Repeat steps **2** and **3** to adjust other tones.

The adjustments made will be stored automatically in "USER."

The current sound mode changes to "USER" automatically.

Tone	Sound element		
	Frequency	Level	Q
BASS	60 Hz, 80 Hz, 100 Hz, 200 Hz	-06 to +06	Q1.0, Q1.25, Q1.5, Q2.0
MIDDLE	0.5 kHz, 1.0 kHz, 1.5 kHz, 2.5 kHz	-06 to +06	Q0.75, Q1.0, Q1.25
TREBLE	10.0 kHz, 12.5 kHz, 15.0 kHz, 17.5 kHz	-06 to +06	Q FIX

Menu operations

- 1  [Hold]
- 2 
- 3 Repeat step 2 if necessary.
 - To return to the previous menu, press **T/P BACK**.
 - To exit from the menu, press **DISP** or **MENU**.

Category	Menu item	Selectable setting, [Initial: <u>Underlined</u>]
DEMO Display demonstration		<ul style="list-style-type: none"> • <u>DEMO ON</u> : Display demonstration will be activated automatically if no operation is done for about 20 seconds. • <u>DEMO OFF</u> : Cancels. (🔍 4)
CLOCK	CLOCK SET Clock setting	[<u>0:00</u>] : Adjust the hour, then the minute. (🔍 4)
	24H/12H Time display mode	<ul style="list-style-type: none"> • <u>24 HOUR</u> : For settings, 🔍 4. • <u>12 HOUR</u>
	CLOCK ADJ *1 Clock adjustment	<ul style="list-style-type: none"> • <u>AUTO</u> : The built-in clock is automatically adjusted using the CT (clock time) data in the Radio Data System signal. • <u>OFF</u> : Cancels.
PRO EQ	BASS	— : For settings, 🔍 23.
	MIDDLE	
	TREBLE	
DISPLAY	DIMMER	<ul style="list-style-type: none"> • <u>DIMMER ON</u> : Dims the display and button illumination. • <u>DIMMER OFF</u> : Cancels.
	SCROLL *2	<ul style="list-style-type: none"> • <u>SCROLL ONCE</u> : Scrolls the displayed information once. • <u>SCROLL AUTO</u> : Repeats scrolling (at 5-second intervals). • <u>SCROLL OFF</u> : Cancels. Pressing DISP for more than one second can scroll the display regardless of the setting.
	TAG DISPLAY	<ul style="list-style-type: none"> • <u>TAG ON</u> : Shows the Tag information while playing MP3/WMA/WAV tracks. • <u>TAG OFF</u> : Cancels.

*1 Takes effect only when CT (clock time) data is received.

*2 Some characters or symbols will not be shown correctly (or will be blanked) on the display.



Category	Menu item	Selectable setting, [Initial: <u>Underlined</u>]
BLUETOOTH ^{*3}		: For Bluetooth operations, 14 – 17. : For Bluetooth settings, 18, 19.
	SSM ^{*4} Strong-station Sequential Memory	<ul style="list-style-type: none"> • SSM 01 – 06 : For settings, 7. • SSM 07 – 12 • SSM 13 – 18
TUNER	AF-REG ^{*5} Alternative frequency/ regionalization reception	<ul style="list-style-type: none"> • AF ON : When the currently received signals become weak, the unit switches to another station (the programme may differ from the one currently received). (The AF indicator lights up.) • AF-REG ON : When the currently received signals become weak, the unit switches to another station broadcasting the same programme. (The AF and REG indicators light up.) • OFF : Cancels.
	PTY-STANDBY ^{*4, *5}	• PTY OFF , PTY codes : Activates PTY Standby Reception with one of the PTY codes (8).
	TA VOLUME ^{*5} Traffic announcement volume	• VOLUME 00 – : — VOLUME 50 (or VOLUME 00 – VOLUME 30) ^{*6} [VOLUME 15]
	P-SEARCH ^{*5} Programme search	<ul style="list-style-type: none"> • SEARCH ON : Activates Programme Search. (9) • SEARCH OFF : Cancels.
	MONO ^{*4} Monaural mode	<ul style="list-style-type: none"> • MONO ON : Activate monaural mode to improve FM reception, but stereo effect will be lost. (7) • MONO OFF : Restore the stereo effect.
	IF BAND Intermediate frequency band	<ul style="list-style-type: none"> • AUTO : Increases the tuner selectivity to reduce interference noises between adjacent stations. (Stereo effect may be lost.) • WIDE : Subject to interference noises from adjacent stations, but sound quality will not be degraded and the stereo effect will remain.

^{*3} Displayed only when the USB Bluetooth Adapter (KS-UBT1) is connected.

^{*4} Displayed only when the source is "FM."

^{*5} Only for FM Radio Data System stations.

^{*6} Depends on the amplifier gain control.





Category	Menu item	Selectable setting, [Initial: <u>Underlined</u>]
AUDIO	FADER *7	R06 – F06 : Adjust the front and rear speaker output balance. [<u>00</u>]
	BALANCE *8	L06 – R06 : Adjust the left and right speaker output balance. [<u>00</u>]
	LOUD Loudness	• LOUD ON : Boost low and high frequencies to produce a well-balanced sound at a low volume level. • LOUD OFF : Cancels.
	VOL ADJUST Volume adjust	VOL ADJ –05 — : Preset the volume adjustment level of each source (except FM), compared to the FM volume level. The volume level will automatically increase or decrease when you change the source. VOL ADJ +05 [<u>VOL ADJ 00</u>] • Before making an adjustment, select the source you want to adjust. • “VOL ADJ FIX” appears on the display if “FM” is selected as the source.
	L/O MODE Line output mode	• SUB.W : Select if the REAR LINE OUT terminals are used for connecting a subwoofer (through an external amplifier). • REAR : Select if the REAR LINE OUT terminals are used for connecting the speakers (through an external amplifier).
	SUB.W FREQ *9 Subwoofer cutoff frequency	• LOW : Frequencies lower than 72 Hz are sent to the subwoofer. • MID : Frequencies lower than 111 Hz are sent to the subwoofer. • HIGH : Frequencies lower than 157 Hz are sent to the subwoofer.
	SUB.W LEVEL *9 Subwoofer level	SUB.W 00 — : Adjust the subwoofer output level. SUB.W 08 [<u>SUB.W 04</u>]
	BEEP Keytouch tone	• BEEP ON : Activates the keypress tone. • BEEP OFF : Deactivates the keypress tone.
	AMP GAIN *10	• LOW POWER : VOLUME 00 — VOLUME 30 (Select if the maximum power of each speaker is less than 50 W to prevent damaging the speakers.) • HIGH POWER : VOLUME 00 — VOLUME 50

*7 If you are using a two-speaker system, set the fader level to “00.”

*8 This adjustment will not affect the subwoofer output.

*9 Displayed only when <L/O MODE> is set to <SUB.W>.

*10 The volume level automatically changes to “VOLUME 30” if you change to <LOW POWER> with the volume level is set higher than “VOLUME 30.”





Category	Menu item	Selectable setting, [Initial: <u>Underlined</u>]
SRC SELECT	AM *11	<ul style="list-style-type: none"> • <u>AM ON</u> : Enable "AM" in source selection. • <u>AM OFF</u> : Disable "AM" in source selection.
	AUX IN *12	<ul style="list-style-type: none"> • <u>AUX ON</u> : Enable "AUX IN" in source selection. • <u>AUX OFF</u> : Disable "AUX IN" in source selection.
	BT AUDIO *13	<ul style="list-style-type: none"> • <u>BT AU ON</u> : Enable "BT FRONT/BT REAR" in source selection. • <u>BT AU OFF</u> : Disable "BT FRONT/BT REAR" in source selection.
USB *14	DRIVECHANGE	: Select to change the drive when a multiple drives device is connected to the USB input terminal (FRONT/REAR).
AUDIOBOOKS *15		<ul style="list-style-type: none"> • <u>NORMAL</u> : You can select the playback speed of the "Audiobooks" sound file in your iPod/iPhone. • <u>FASTER</u> • <u>SLOWER</u> * Initial selected item depends on your iPod/iPhone setting.
IPOD SWITCH *15		<ul style="list-style-type: none"> • <u>HEAD MODE</u> : Controls iPod playback through the unit. • <u>IPOD MODE</u> : Controls iPod playback through the iPod/iPhone. • <u>EXT MODE</u> *16 : The sound of any functions (musics, games, applications, etc.) running on the connected iPod/iPhone is emitted through the speakers connected to this unit.

*11 Displayed only when any source other than "AM" is selected.

*12 Displayed only when any source other than "AUX IN" is selected.

*13 Displayed only when any source other than "BT FRONT/BT REAR" is selected.

*14 Displayed only when the source is "USB FRONT/USB REAR."

*15 Displayed only when the source is "IPOD FRONT/IPOD REAR."

*16 While in <EXT MODE>, the display always show "EXT MODE."

More about this unit

Basic operations

General

- If you turn off the power while listening to a track, playback will start from where it had been stopped previously next time you turn on the power.
- If no operation is done for about 60 seconds after pressing **MENU** button, the operation will be canceled.

Tuner operations

Storing stations in memory

- During SSM search...
 - All previously stored stations are erased and the stations are stored anew.
 - When SSM is over, the station stored in the lowest preset number will be automatically tuned in.
- When storing a station manually, the previously preset station is erased when a new station is stored in the same preset number.





FM Radio Data System operations

- Network-Tracking Reception requires two types of Radio Data System signals—PI (Programme Identification) and AF (Alternative Frequency) to work correctly.
- If a Traffic Announcement is received by TA Standby Reception, the volume level automatically changes to the preset level (TA VOLUME) if the current level is lower than the preset level.
- When Alternative Frequency Reception is activated (with AF selected), Network-Tracking Reception is also activated automatically.

Disc/USB operations

Caution for DualDisc playback

- The Non-DVD side of a "DualDisc" does not comply with the "Compact Disc Digital Audio" standard. Therefore, the use of Non-DVD side of a DualDisc on this product may not be recommended.

General

- This unit has been designed to reproduce CDs/CD Texts, and CD-Rs (Recordable)/CD-RWs (Rewritable) in audio CD (CD-DA), MP3 and WMA formats.
- If you change the source while listening to a disc, playback stops. Next time you select "CD" as the playback source, playback will start from where it had been stopped previously.
- When a disc is inserted upside down, "PLEASE" and "EJECT" appear alternately on the display. Press ▲ to eject the disc.
- If the ejected disc is not removed within 15 seconds, it is automatically inserted into the loading slot again to protect it from dust. Playback starts automatically.

- MP3 and WMA "tracks" (words "file" and "track" are used interchangeably) are recorded in "folders."
- While fast-forwarding or reversing on an MP3 or WMA disc, you can only hear intermittent sounds.

Playing a CD-R or CD-RW

- Use only "finalized" CD-Rs or CD-RWs.
- This unit can only play back files of the same type as those detected first if a disc includes both audio CD (CD-DA) files and MP3/WMA files.
- This unit can play back multi-session discs; however, unclosed sessions will be skipped while playing.
- Some CD-Rs or CD-RWs may not play back on this unit because of their disc characteristics, or for the following reasons:
 - Discs are dirty or scratched.
 - Moisture condensation has occurred on the lens inside the unit.
 - The pickup lens inside the unit is dirty.
 - The files on the CD-R/CD-RW are written using the "Packet Write" method.
 - There are improper recording conditions (missing data, etc.) or media conditions (stained, scratched, warped, etc.).
- CD-RWs may require a longer readout time since the reflectance of CD-RWs is lower than that of regular CDs.
- Do not use the following CD-Rs or CD-RWs:
 - Discs with stickers, labels, or a protective seal stuck to the surface.
 - Discs on which labels can be directly printed by an ink jet printer.Using these discs under high temperature or high humidity may cause malfunctions or damage to the unit.





Playing an MP3/WMA disc

- This unit can play back MP3/WMA files with the extension code <.mp3> or <.wma> (regardless of the letter case—upper/lower).
- This unit can show the names of albums, artists (performer), and Tag (Version 1.0, 1.1, 2.2, 2.3, or 2.4) for MP3 files and show WMA Tag.
- This unit can display only one-byte characters. No other characters can be correctly displayed.
- This unit can play back MP3/WMA files meeting the conditions below:
 - Bit rate of MP3/WMA: 5 kbps — 320 kbps
 - Sampling frequency of MP3:
 - 32 kHz, 44.1 kHz, 48 kHz (for MPEG-1)
 - 16 kHz, 22.05 kHz, 24 kHz (for MPEG-2)
 - Sampling frequency of WMA:
 - 8 kHz — 48 kHz
- The maximum number of characters for file/folder names is 25 characters (including <.mp3>, <.wma>); 128 characters for MP3/WMA Tag.
- This unit can recognize a total of 20 000 files and 2 000 folders (999 files per folder). However, the display can show until 999 folders/files.
- This unit can play back files recorded in VBR (variable bit rate).
Files recorded in VBR have a discrepancy in the elapsed time display, and do not show the actual elapsed time. In particular, this difference becomes noticeable after performing the search function.
- This unit cannot play back the following files:
 - MP3 files encoded in MP3i and MP3 PRO format.
 - MP3 files encoded in an inappropriate format.
 - MP3 files encoded with Layer 1/2.
 - WMA files encoded in lossless, professional, and voice format.

- WMA files which are not based upon Windows Media® Audio.
- WMA files copy-protected with DRM.
- Files which have data such as AIFF, ATAC3, etc.
- The search function works but search speed is not constant.

Playing MP3/WMA/WAV tracks from a USB device

- While playing from a USB device, the playback order may differ from other players.
- This unit may be unable to play back some USB devices or some files due to their characteristics or recording conditions.
- This unit is compatible with the USB Full-Speed.
- Depending on the shape of the USB devices and connection ports, some USB devices may not be attached properly or the connection might be loose.
- This unit may not work properly with some USB hub or USB card reader.
- If the connected USB device does not have the correct files, “NO FILE” appears.
- This unit can show Tag (Version 1.0, 1.1, 2.2, 2.3, or 2.4) for MP3 and WMA/WAV Tag.
- This unit can play back MP3/WMA/WAV files meeting the conditions below:
 - MP3:
 - Bit rate: 32 kbps — 320 kbps (for MPEG-1)
 - 8 kbps — 160 kbps (for MPEG-2)
 - Sampling frequency:
 - 32 kHz, 44.1 kHz, 48 kHz (for MPEG-1)
 - 16 kHz, 22.05 kHz, 24 kHz (for MPEG-2)
 - WMA:
 - Bit rate: 5 kbps — 320 kbps
 - Sampling frequency: 8 kHz — 48 kHz
 - Channel: 1 ch/2 ch
 - WAV:
 - Bit rate: Linear PCM at 705 kbps and 1 411 kbps
 - Sampling frequency: 44.1 kHz
 - Channel: 1 ch/2 ch





- This unit can play back MP3 files recorded in VBR (variable bit rate).
- The maximum number of characters for folder and file names is 25 characters (including <.mp3>, <.wma>, <.wav>); 128 characters for MP3/WMA/WAV Tag.
- This unit can recognize a total of 20 000 files and 2 000 folders (999 files per folder). However, the display can show until 999 folders/files.
- The unit cannot recognize a USB mass storage class device whose rating is other than 5 V and exceeds 500 mA.
- USB devices equipped with special functions such as data security functions cannot be used with the unit.
- Do not use a USB device with 2 or more partitions.
- When connecting with a USB cable, use the USB 2.0 cable.
- This unit may not recognize some of the USB device connected through a USB card reader.
- This unit may not play back files in a USB device properly when using a USB extension cord.
- This unit cannot assure proper functions or supply power to all types of USB devices

Bluetooth operations

- While driving, do not perform complicated operation such as dialing the numbers, using phonebook, etc. When you perform these operations, stop your car in a safe place.
- Some Bluetooth devices may not be connected to this unit depending on the Bluetooth version of the device.
- If you connect a different USB Bluetooth Adapter, all the registered devices and information will be cleared.
- This unit may not work for some Bluetooth devices.
- Connecting condition may vary depending on the circumstances around you.

- If you turn off the unit, detach the control panel, or unplug the USB Bluetooth Adapter during a phone call conversation, the Bluetooth connection is disconnected. Continue the conversation using your mobile phone.
- When the unit is turned off, the device is disconnected.

iPod/iPhone operations

- You can control the following types of iPods/iPhone:
 - iPod with video (5th Generation)*
 - iPod classic
 - iPod nano (1st Generation)*
 - iPod nano (2nd, 3rd, 4th, 5th Generation)
 - iPod touch
 - iPod touch (2nd Generation)
 - iPhone/iPhone 3G/iPhone 3GS
- * <IPOD MODE> and <EXT MODE> are not available.
- It is not possible to browse video files on the "Videos" menu in <HEAD MODE>.
- If the iPod does not play correctly, please update your iPod software to the latest version. For details about updating your iPod, visit <<http://www.apple.com>>.
- When you turn on this unit, the iPod is charged through this unit.
- iPod shuffle cannot be used with this unit.
- The song order displayed on the selection menu of this unit may differ from that of the iPod.
- The text information may not be displayed correctly (eg. accented letters).
- This unit can display up to 128 characters (ASCII code).




Maintenance

How to clean the connectors

Frequent detachment will deteriorate the connectors.

To minimize this possibility, periodically wipe the connectors with a cotton swab or cloth moistened with alcohol, being careful not to damage the connectors.



Connectors

Moisture condensation


Moisture may condense on the lens inside the unit in the following cases:

- After starting the heater in the car.
 - If it becomes very humid inside the car.
- Should this occur, the unit may malfunction. In this case, eject the disc and leave the unit turned on for a few hours until the moisture has evaporated.

How to handle discs

When removing a disc from its case, press down the center holder of the case and lift the disc out, holding it by the edges.

Center holder



- Always hold the disc by the edges. Do not touch its recording surface.

When storing a disc in its case, gently insert the disc around the center holder (with the printed surface facing up).

- Make sure to store discs in cases after use.

To keep discs clean


A dirty disc may not play correctly. If a disc does become dirty, wipe it with a soft cloth in a straight line from center to edge.



- Do not use any solvents (for example, conventional record cleaner, spray, thinner, benzene, etc.) to clean discs.

To play new discs

New discs may have some rough spots around the inner and outer edges. If such a disc is used, this unit may reject the disc.



To remove these rough spots, rub the edges with a pencil or ball-point pen, etc.

Do not use the following discs:

Single CD (8 cm disc) 	Warped disc
Sticker and sticker residue 	Stick-on label
Unusual shape 	C-thru Disc (semitransparent disc)
Transparent or semitransparent parts on its recording area 	

Troubleshooting

	Symptom	Remedy/Cause
General	Sound cannot be heard from the speakers.	<ul style="list-style-type: none"> • Adjust the volume to the optimum level. • Make sure the unit is not muted/paused (🔊 6). • Check the cords and connections.
	"PROTECT" appears on the display and no operations can be done.	<p>Check to be sure the terminals of the speaker leads are covered with insulating tape properly, then reset the unit (🔊 3).</p> <p>If "PROTECT" does not disappear, consult your JVC IN-CAR ENTERTAINMENT dealer or a company supplying kits.</p>
	The unit does not work at all.	Reset the unit. (🔊 3)
	"AM," "AUX IN," or "BT AUDIO" cannot be selected.	Check the <SRC SELECT> setting. (🔊 27)
FM/AM	SSM automatic presetting does not work.	Store stations manually.
	Static noise while listening to the radio.	Connect the aerial firmly.
Disc playback	Disc cannot be played back.	Insert the disc correctly.
	<ul style="list-style-type: none"> • CD-R/CD-RW cannot be played back. • Tracks on the CD-R/CD-RW cannot be skipped. 	<ul style="list-style-type: none"> • Insert a finalized CD-R/CD-RW. • Finalize the CD-R/CD-RW with the component which you used for recording.
	Disc can neither be played back nor ejected.	<ul style="list-style-type: none"> • Unlock the disc. (🔊 10) • Eject the disc forcibly. (🔊 3)
	Disc sound is sometimes interrupted.	<ul style="list-style-type: none"> • Stop playback while driving on rough roads. • Change the disc. • Check the cords and connections.
	"NO DISC" appears on the display.	Insert a playable disc into the loading slot.
	"PLEASE" and "EJECT" appear alternately on the display.	Press ▲, then insert a disc correctly.



	Symptom	Remedy/Cause
MP3/WMA playback	Disc cannot be played back.	<ul style="list-style-type: none"> Use a disc with MP3/WMA tracks recorded in a format compliant with ISO 9660 Level 1, Level 2, Romeo, or Joliet. Add the extension code <.mp3> or <.wma> to the file names.
	Noise is generated.	Skip to another track or change the disc. (Do not add the extension code <.mp3> or <.wma> to non-MP3 or WMA tracks.)
	A longer readout time is required ("READING" keeps flashing on the display).	Do not use too many hierarchical levels and folders.
	Tracks are not played back in the order you have intended.	The playback order is determined by the file name. Folder with numbers on the initial as their names are sorted in numerical order. However, folder with no numbers on the initial of their names are sorted according to the file system of the CD.
	"NOT SUPPORT" appears on the display and track skips.	Skip to the next track encoded in an appropriate format or to the next non-copy-protected WMA track.
	The elapsed playing time is not correct.	This sometimes occurs during playback. This is caused by how the tracks are recorded on the disc.
	The correct characters are not displayed (e.g. album name).	This unit can only display letters (upper case), numbers, and a limited number of symbols.
USB device playback	Noise is generated.	The track played back is not an MP3/WMA/WAV track. Skip to another file. (Do not add the extension code <.mp3>, <.wma>, or <.wav> to non-MP3/WMA/WAV tracks.)
	"READING" keeps flashing on the display.	<ul style="list-style-type: none"> Readout time varies depending on the USB device. Do not use too many hierarchy or folders. Turn off the power then on again. Reattach the USB device again.
	"NO FILE" appears on the display.	Check whether the selected folder, the connected USB device, or the iPod/iPhone contains a playable file.
	"NOT SUPPORT" appears and track skips.	Check whether the track is a playable file format.





	Symptom	Remedy/Cause
USB device playback	Tracks/folders are not played back in the order you have intended.	The playback order is determined by the file name. Folders with numbers on the initial of their names are sorted in numerical order. However, folders with no numbers on the initial of their names are sorted according to the file system of the USB device.
	<ul style="list-style-type: none"> • "READ FAILED" or "NO USB" appears. • The unit cannot detect the USB device. 	<ul style="list-style-type: none"> • Check whether the connected USB device or the iPod/iPhone is compatible with this unit. • The USB device is not connected properly. Connect the USB device again.
	While playing a track, sound is sometimes interrupted.	The tracks have not been properly copied into the USB device. Copy tracks again into the USB device, and try again.
	Correct characters are not displayed (e.g. album name).	This unit can only display letters (upper case), numbers, and a limited number of symbols.
Bluetooth	The unit does not detect the Bluetooth device.	<ul style="list-style-type: none"> • Search from the Bluetooth device again. • Reset the unit, then search from the Bluetooth device again.
	The unit does not make pairing with the Bluetooth device.	Enter the same PIN code for both the unit and target device.
	Echo or noise occurs.	Adjust the microphone unit's position.
	Phone sound quality is poor.	<ul style="list-style-type: none"> • Reduce the distance between the unit and the Bluetooth mobile phone. • Move the car to a place where you can get a better signal reception.
	The unit does not response when you tried to copy the phonebook to the unit.	You may have tried to copy the same entries (as stored) to the unit. Press DISP or T/P BACK to exit.
	The sound is interrupted or skipped during playback of a Bluetooth audio player.	<ul style="list-style-type: none"> • Reduce the distance between the unit and the Bluetooth audio player. • Disconnect the device connected for Bluetooth Phone. • Turn off, then turn on the unit. • Connect the player again, when the sound is not yet restored.
	The connected audio player cannot be controlled.	<ul style="list-style-type: none"> • Check whether the connected audio player supports AVRCP (Audio/Video Remote Control Profile). (Operations depend on the connected audio player.) • Disconnect and connect the Bluetooth player again.





	Symptom	Remedy/Cause
Bluetooth	"VOICE DIAL" is not successful.	<ul style="list-style-type: none"> • Use "VOICE DIAL" calling method in a more quiet environment. • Reduce the distance from the microphone when you speak the name. • Change the <NR/EC MODE> to <OFF> (🔍 19), then try again.
iPod/iPhone	The iPod/iPhone does not turn on or does not work.	<ul style="list-style-type: none"> • Check the connecting cable and its connection. • Update the firmware version of the iPod/iPhone. • Charge the battery of the iPod/iPhone. • Reset the iPod/iPhone. • Check whether <IPOD SWITCH> setting is appropriate (🔍 27).
	The sound is distorted.	Deactivate the equalizer on the iPod/iPhone.
	A lot of noise is generated.	Turn off (uncheck) the "VoiceOver" feature of the iPod. For details, visit < http://www.apple.com >.
	Playback stops.	The headphones are disconnected during playback. Restart the playback operation.
	"NO FILE" appears on the display.	No tracks are stored. Import tracks to the iPod/iPhone.
	"RESTRICTED" appears on the display.	Check whether the connected iPod/iPhone is compatible with this unit (🔍 30).

JVC bears no responsibility for any loss of data in an iPod/iPhone and/or USB mass storage class device while using this System.


- Microsoft and Windows Media are either registered trademarks or trademarks of Microsoft Corporation in the United States and/or other countries.
- The Bluetooth word mark and logos are owned by the Bluetooth SIG, Inc. and any use of such marks by Victor Company of Japan, Limited (JVC) is under license. Other trademarks and trade names are those of their respective owners.
- "Made for iPod" means that an electronic accessory has been designed to connect specifically to iPod and has been certified by the developer to meet Apple performance standards.
- "Works with iPhone" means that an electronic accessory has been designed to connect specifically to iPhone and has been certified by the developer to meet Apple performance standards.
- Apple is not responsible for the operation of this device or its compliance with safety and regulatory standards.
- iPod is a trademark of Apple Inc., registered in the U.S. and other countries.
- iPhone is a trademark of Apple Inc.



Specifications

AUDIO AMPLIFIER SECTION	Maximum Power Output:	Front/ Rear:	50 W per channel	
	Continuous Power Output (RMS):	Front/ Rear:	20 W per channel into 4 Ω, 40 Hz to 20 000 Hz at no more than 1% total harmonic distortion.	
	Load Impedance:		4 Ω (4 Ω to 8 Ω allowance)	
	Tone Control Range:	Bass:	±12 dB (60 Hz, 80 Hz, 100 Hz, 200 Hz) Q1.0, Q1.25, Q1.5, Q2.0	
		Middle:	±12 dB (0.5 kHz, 1.0 kHz, 1.5 kHz, 2.5 kHz) Q0.75, Q1.0, Q1.25	
		Treble:	±12 dB (10.0 kHz, 12.5 kHz, 15.0 kHz, 17.5 kHz) Q (Fixed)	
	Frequency Response:		40 Hz to 20 000 Hz	
	Signal-to-Noise Ratio:		70 dB	
	Line-Out Level/Impedance:		2.5 V/20 kΩ load (full scale)	
	Subwoofer-Out Level/Impedance:		2.5 V/20 kΩ load (full scale)	
Output Impedance:		1 kΩ		
Other Terminal:		USB input terminal, USB rear cable, Aerial input, AUX (auxiliary) input jack, Steering wheel remote input		
TUNER SECTION	Frequency Range:	FM:	87.5 MHz to 108.0 MHz	
		AM:	MW: 522 kHz to 1 620 kHz LW: 144 kHz to 279 kHz	
	FM Tuner:	Usable Sensitivity:	9.3 dBf (0.8 μV/75 Ω)	
		50 dB Quieting Sensitivity:	16.3 dBf (1.8 μV/75 Ω)	
		Alternate Channel Selectivity (400 kHz):	65 dB	
		Frequency Response:	40 Hz to 15 000 Hz	
		Stereo Separation:	40 dB	
	MW Tuner:	Sensitivity:	20 μV	
		Selectivity:	40 dB	
	LW Tuner:	Sensitivity:	50 μV	



CD PLAYER SECTION	Type:		Compact disc player	
	Signal Detection System:		Non-contact optical pickup (semiconductor laser)	
	Number of Channels:		2 channels (stereo)	
	Frequency Response:		5 Hz to 20 000 Hz	
	Dynamic Range:		96 dB	
	Signal-to-Noise Ratio:		98 dB	
	Wow and Flutter:		Less than measurable limit	
	MP3 Decoding Format: (MPEG1/2 Audio Layer 3)		Max. Bit Rate: 320 kbps	
	WMA (Windows Media® Audio) Decoding Format:		Max. Bit Rate: 320 kbps	
USB SECTION	USB Standard:		USB 1.1, USB 2.0	
	Data Transfer Rate (Full Speed):		Max. 12 Mbps	
	Compatible Device:		Mass storage class (except HDD)	
	Compatible File System:		FAT 32/16/12	
	Playable Audio Format:		MP3/WMA/WAV	
	Max. Current:		DC 5 V  500 mA	
BLUETOOTH	Version:		Bluetooth 2.0 certified	
	Power Class:		Class 2 Radio (possible distance 10 m)	
	Service Area:		10 m	
	Profile:		HFP 1.5, OPP 1.1, A2DP 1.2, AVRCP 1.3, PBAP 1.0	
GENERAL	Power Requirement:	Operating Voltage:	DC 14.4 V (11 V to 16 V allowance)	
	Grounding System:		Negative ground	
	Allowable Operating Temperature:		0°C to +40°C	
	Dimensions (W × H × D): (approx.)	Installation Size:	182 mm × 52 mm × 160 mm	
		Panel Size:	188 mm × 58 mm × 12 mm	
Mass:		1.4 kg (excluding accessories)		

Design and specifications are subject to change without notice.





Merci pour avoir acheté un produit JVC.

Veuillez lire attentivement toutes les instructions avant d'utiliser l'appareil afin de bien comprendre son fonctionnement et d'obtenir les meilleures performances possibles.

IMPORTANT POUR PRODUITS LASER

1. PRODUIT LASER CLASSE 1
2. **ATTENTION:** N'ouvrez pas le couvercle supérieur. Il n'y a aucune pièce réparable par l'utilisateur à l'intérieur de l'appareil; confiez toute réparation à un personnel qualifié.
3. **ATTENTION:** Rayonnement laser visible et/ou invisible de classe 1M une fois ouvert. Ne pas regarder directement avec des instruments optiques.
4. REPRODUCTION DE L'ÉTIQUETTE: ÉTIQUETTE DE PRÉCAUTION PLACÉE À L'EXTÉRIEUR DE L'APPAREIL.

CAUTION VISIBLE AND/OR INVISIBLE CLASS 1M LASER RADIATION WHEN OPEN. DO NOT VIEW DIRECTLY WITH OPTICAL INSTRUMENTS. IEC60825-1:2001 (ENG)	ATTENTION RAYONNEMENT LASER VISIBLE ET/OU INVISIBLE DE CLASSE 1M UNE FOIS OUVERT. NE PAS REGARDER DIRECTEMENT AVEC DES INSTRUMENTS OPTIQUES. (FRA)	AVISO RADIACIÓN LASER DE CLASE 1M VISIBLE Y/O INVISIBLE CUANDO ESTA ABIERTO. NO MIRAR DIRECTAMENTE CON INSTRUMENTAL ÓPTICO. (ESP)	VARNING SYNLIG OCH/ELLER OBSYNLIG LASERSTRÅLNING. KLASS 1M, NÄR DENNA DEL ÄR ÖPPNAD. BETRAKTA EJ STRÅLEN MED OPTISKA INSTRUMENT. (SWE)	注意 ここを開くと可視 及び/または不可視 レーザー放射が 出ます。 光学機器で直視 しないでください。 (JPN)	CAUTION VISIBLE AND/OR INVISIBLE CLASS II LASER RADIATION WHEN OPEN. DO NOT STARE INTO BEAM. FDA 21 CFR (ENG)
--	--	---	--	--	--



Produits



Pile

Informations relatives à l'élimination des appareils et des piles usagés, à l'intention des utilisateurs

[Union européenne seulement]

Ces symboles signifient que le produit et les piles ne doivent pas être éliminés en tant que déchet ménager à la fin de son cycle de vie.

Si vous souhaitez éliminer ce produit et les piles, faites-le conformément à la législation nationale ou autres règles en vigueur dans votre pays et votre municipalité.

En éliminant correctement ce produit, vous contribuez à la conservation des ressources naturelles et à la prévention des éventuels effets négatifs sur l'environnement et la santé humaine.

Notification:

La marque Pb en dessous du symbole des piles indique que cette pile contient du plomb.

Avertissement:

Si vous souhaitez opérer l'appareil pendant que vous conduisez, assurez-vous de bien regarder autour de vous afin de ne pas causer un accident de la circulation.

Pour sécurité...

- N'augmentez pas trop le volume car cela bloquerait les sons de l'extérieur rendant la conduite dangereuse.
- Arrêtez la voiture avant de réaliser toute opération compliquée.

Température à l'intérieur de la voiture...

Si votre voiture est restée garée pendant longtemps dans un climat chaud ou froid, attendez que la température à l'intérieur de la voiture redevienne normale avant d'utiliser l'appareil.

Précautions sur le réglage du volume:

Les appareils numériques (CD/USB) produisent très peu de bruit par rapport aux autres sources. Réduisez le volume avant de reproduire ces sources numériques afin d'éviter d'endommager les enceintes par la soudaine augmentation du niveau de sortie.

